WARWICK Sundec®

Regular care

Where possible store away from direct sunlight when not in use to prolong fabric life. Vacuum regularly using low suction. Rotate reversible cushions regularly.

Cleaning

Do not remove cushion covers for separate cleaning even though they have zippers. Clean with hot-water extraction machine (hot). Professional cleaning recommended. Use only upholstery detergent. Do not wet filling. Allow to naturally dry before re-use.

or

May be shampoo cleaned using upholstery shampoo only. Do not use dishwashing or laundry detergents. Do not wet filling. Do not scrub with stiff brush. Allow to naturally dry before re-use.

Spot Cleaning

Treat spills and stains as soon as possible. Gently scrape any soil or mop any liquid from the surface of the fabric. Do not scrub. Apply proprietary cleaning agents strictly according to instructions to remove the residue of the spill. Do not saturate the fabric or interior with water or other cleaning liquids. May be spot cleaned with dry cleaning solvent.

Bleach Cleaning/Disinfection

Mix 5% of household bleach (sodium hypochlorite) with 95% water (One 250mL cup of household bleach in 5L of water). Pre-test cleaning method on a hidden part of the furniture. The bleach solution can remain on the fabric surface for up to 10-minutes after which the bleach solution must be thoroughly rinsed from the fabric using a water extraction machine filled with cold water. Once thoroughly rinsed, extract any residual moisture and allow to dry at room temperature. Furniture must be dry before being reused.

WARNING: Sodium hypochlorite bleach is corrosive. Avoid contact with the skin. Use PVC gloves and follow the safety instructions of the bleach manufacturer. Please also be mindful not to apply the bleach solution to the frame of the furniture or any floor coverings without further testing.

SUNDEC® is the registered trademark of Warwick Fabrics.

For more information visit www.warwick.com.au